

MODEL LT - Installation Suggestions and Hints

WARNING

DO NOT remove the looped safety pin in the extinguisher head until the pull cable is installed. The extinguisher will discharge if the pin is removed prior to inserting the actuation cable.

1. Cylinder Mounting

We recommend that the extinguisher be mounted horizontally, cross wise in the vehicle. Observe temperature limits on label. Mount so you can see the gauge and label. Tech inspectors like to verify the gauge readings and service info from the label.

2. Discharge Head

- a) The Model LT extinguisher has a unique design that allows the cylinder to be positioned and then the top of the discharge head rotated for the pull cable hook-up, or push knob location. To rotate the head – loosen the set screw at the perimeter of the discharge head – rotate it to the desired position – tighten the setscrew. The head may be a little tight when rotated – this is normal. The discharge ports on the Model LT do not rotate.
- b) The extinguisher comes with 1 or 2 outlets (#4 flare fitting) installed in the head. The 2nd port may be plugged. To use the 2nd port – remove the plug and install the supplied fitting.

3. Pull Cable Activation – see picture on back page

- a) The safety pin or the pull cable is used to keep the spring loaded plunger in the “cocked” position. **Either of these must be in place or the extinguisher will discharge!!**
- b) The hole in which the inner cable passes through is close tolerance, so the inner cable can be a little hard to get through.
- c) To install the pull cable we suggest the following:
 1. If you use the cable as supplied, sand or file the end of the inner cable to a smooth blunt end before inserting it through the head.
 2. If you need to shorten the cable, remove the inner cable from the outer cable conduit. Install the outer cable and secure it. It can be cut with a pair of heavy wire cutters, then insure that the inner cable run through it smoothly.
 3. Install the inner cable all the way through the conduit and let it pass through the head of the extinguisher.
 4. The end of inner cable **MUST NOT** extend out of the head more than **1 inch**. Ensure that the cut end is free from burrs. We suggest that you sand or file a smooth blunt end on the inner cable.

When the pull cable is installed you can remove the safety pin. The safety pin must be removed for the extinguisher to activate.

4. Push Knob Activation – see picture on back page


- a) If you purchased a push knob activation extinguisher, we suggest you mount the extinguisher within easy reach of the driver. The safety pin is installed in the knob shaft and must be removed to activate the extinguisher. Ensure that the set screw on the side of the discharge head is tight after you set the location of the push knob.

5. Discharge Line and Nozzles


- a) Some kits are supplied with 10 ft. of ¼ inch aluminum or steel tubing. Do not crimp the tubing when routing, use a tube bender. Slide the flare nuts and ferrules onto the lines before flaring the tube. A single flare is all that is required. A normal flaring tool can be used, the type you can get at any hardware store. The fittings have a 37 degree AN type of flare.
- b) The spray nozzles provide about a 120 degree spray pattern, both vertically and horizontally. Mount in the desired location to provide an unobstructed spray to the desired location. **DO NOT** use any other brand of spray nozzles with Safecraft extinguisher systems.
- c) If your kit came with blue and red nozzles, use the blue nozzle for the driver and the red nozzles for the engine and or fuel cell. Otherwise use the red nozzles for all locations.

NO WARRANTIES, EXPRESSED OR IMPLIED ARE MADE FOR THE SUITABILITY OF THIS PRODUCT FOR ANY PURPOSE. NO WARRANTY OR REPRESENTATION IS MADE AS TO THIS PRODUCTS ABILITY TO PROTECT THE USER FROM ANY INJURY OR DEATH. THE END USER MUST DETERMINE THE SUITABILITY OF THIS PRODUCT FOR THEIR APPLICATION

Model LT – Pull Cable



Model LT – Push Knob



Safety pin on push knob not shown for clarity