

SAFECRAFT Head Net Ratchet

The Safecraft Head Net Ratchet can be reset and the webbing un-wound on the ratchet spindle by following these steps.

Before you start

- A) Make sure the head net is not installed or under tension
- B) Secure end of webbing gently in a vice – or have another person hold it. Don't clamp it hard in the vice, just enough to hold it.

Resetting the ratchet

- 1) Press and hold the release lever all the way forward from it's normal position
- 2) While holding the lever (1) forward, turn the ½ inch hex head pin (2) with a wrench until just before the next click, then turn it back while slowly while keeping a little pull tension on the whole housing. The webbing will un-wind from the hex head pin and the wrench will turn in the loosening direction.
- 3) If you go to far (past the next click), repeat steps 1 & 2 above.

Caution

Before installing the head net

- 1) If the webbing has been completely un-wound from the pin, wind the webbing onto the pin for 8-9 clicks (not turns) before installing the head net. **Failure to do this may result in the webbing coming loose from the pin.** After the initial 8-9 clicks, the head net is ready to install.

